## IMPORTANT | | READ THIS FIRST | |

## **HOW TO INSTALL**

## INFUSED COLOR PPE



## Color PPF does not have the exact same procedures as vinyl. However, by following these tested techniques you will acheive a successful Color PPF Installation:

- Install using **WATER ONLY**
- If the Color PPF is too sticky, add one drop of soap at a time until the desired tack is reached.
- After you have finished a panel, let it dry completely at all edges before wrapping around the edges.
- We suggest installing many panels first before attempting to wrap any edges. This will save you time instead of waiting for individual panels to dry and finishing each panel's edge before moving to the next.
- When an edge is very curvy try to keep the edge as dry as possble. Please also wrap it dry for best results.

Color PPF takes longer to install than Clear PPF because you must wrap all edges so you don't see the original color underneath. Because of this, you must charge more than a Clear PPF installation. You can not expect to do a Color PPF job as quickly as vinyl or Clear PPF...it is 4 X thicker than vinyl!